

Powder-coated surfaces



CLEANING AND CARE INSTRUCTIONS

For the optimal care and cleaning of powder-coated surfaces, the following recommendations should be observed

- Use only soft cloths or cotton waste. Avoid heavy rubbing.
- Clean with pure water – cold or lukewarm – or with a small amount of neutral or slightly alkaline detergent.
- To remove grease stains and fingerprints, use a commercially available microfiber cloth.
- For stubborn stains, such as greasy or oily substances, cleaning can be carried out with aromatic-free petrol hydrocarbons (check on non-visible surfaces beforehand).
- Do not allow the cleaning agent to take effect for long periods. If necessary, repeat the cleaning process after 24 hours. Immediately after cleaning, rinse with clean, cold water.
- Do not use any scratching or abrasive agents.
- Do not use any acidic or strongly alkaline cleaning or wetting agents.
- Do not use organic solvents containing esters, ketones, alcohols, aromatics, glycol ethers, halogenated hydrocarbons or the like.
- Surface and cleaning agent temperature < 25°C (do not use steam jet devices).
- Do not use high-pressure cleaning equipment.