

Upholstery Fabrics



CARE AND CLEANING INSTRUCTIONS

Please follow the manufacturer's instructions

Camira fabrics and vinyl have been developed to withstand regular cleaning and, when carried out in accordance with the relevant guidelines, routine disinfection. Always follow the instructions provided by the manufacturer of the cleaning or disinfecting product. We recommend testing the product first on an inconspicuous area of the material.

The information and recommendations provided are based on technical research and testing carried out by Camira or by certified independent laboratories. Cleaning and disinfection may affect textiles in three principal areas: colour fastness, flame retardancy and material integrity. The extent of these effects depends on the frequency of cleaning or disinfection.

The use of cleaning, care or disinfection methods other than those described in these instructions may invalidate the product warranty.

Water and Upholstery Soap

Use clean water or a mild liquid soap diluted in warm water. Wipe the upholstery with a clean cloth that has been thoroughly wrung out, taking care not to over-wet the fabric. Alternatively, an extraction cleaner may be used to clean, rinse and remove excess moisture simultaneously. Allow the upholstery to dry naturally.

→ Suitable for: All fabrics and vinyl.

Alcohol

Alcohol- and ethanol-based disinfectants are fast-acting against bacteria, viruses and fungi. Suitable products include sprays and wipes containing a 75% alcohol solution. Always follow the manufacturer's instructions. After disinfection, remove any residues by wiping the surface with clean water.

→ Suitable for: Polypropylene, polyester, Trevira CS and vinyl.

Steam

Steam cleaning and disinfection provide a chemical-free cleaning method, using a combination of heat and pressure to remove dirt and stains while eliminating microorganisms. Steam temperatures typically reach up to 180 °C.

→ Suitable for: Wool, wool bast fibre, polyester and Trevira CS.